

Hmd-202 / Center Punch Installation Instructions for Non-Raked Bikes

1. Remove outer fairing and separate inner fairing from aluminum bracket. You will need to cut out the space where the stock display is located so the media player will clear. Shown in (Pic. A)



2. You will need to fit the center punch part to the inner fairing. There will be a slight gap on the top right and left of the part where it attaches on top. Mark where the end of the part lands. Sand down where the part will attach to the inner fairing using 80 grit sand paper. Sand the inside of the part also. Glue the parts together using a 2-part quick dry epoxy. Do not over do the glue, it will make the clean up harder to do. Let dry overnight, then bodywork area to make a smooth transition between the inner fairing and the part. Shown in (Pic B)



3. You will need to install the bracket kit for clearance. There are 4 larger washers that are used for clearance (Pic. C). Install them between the stock triple tree and the bracket. Use the factory bolts that hold on the mounting brackets for the silver inner fairing bracket. Make sure to install the bracket with the pointed side of the bracket going down and the bolts holes going up and out, as in (Pic. D)



Pic. C



Pic.D

4. Using the bolts, washers, and nuts provided, attach the stock inner aluminum fairing bracket to the new bracket you just attached. Shown in (Pic. E)



Pic. E

5. Reattach the inner aluminum bracket, along with the inner fairing. You are now ready to install the media player.